



# NITROGEN PURGING & BLOW GUN KITS



The **GENTEC Nitrogen Purging Kit** is designed for purging refrigerant systems, leak testing, cleaning coils & condensate drain lines, and much more using nitrogen, a dry inert gas.

Genstar Technologies Co., Inc.  
4525 Edison Ave, Chino, CA 91710, U.S.A.  
Tel: 909-606-2726

[www.genstartech.com](http://www.genstartech.com)

**GENTEC Nitrogen Purging and Blow Gun Kits** include a chrome-plated compressed air blow gun with Standard Safety Tip and solid brass internal parts. The blow gun is lightweight and designed to fit comfortably in the user's hand. It complies with OSHA 1910.242b and 1910.95 which require that compressed air be limited to 30 PSI at the nozzle outlet. The safety tip includes a safety by-pass which prevents excessive pressure build-up in the gun if the nozzle becomes clogged. Accessories, such as high or low-pressure regulators, blow gun hose, standard safety tip, rubber tip for blowing out lines and 6" extension needle tip are available. GENTEC Nitrogen Purging and Blow Gun Kits include a high-pressure regulator for Nitrogen and carrying stands for 20 or 40 cu. ft. nitrogen cylinders.

## GKNP NITROGEN PURGE & BLOW GUN KITS

### GKNP

- HBG-6 Blow Gun Hose (6ft.)
- B306 OSHA Rated Blow Gun with Safety Tip
- 452IN-450F Nitrogen Regulator

### GKNP20-TC

- CY20-580 20 cu. Ft. Tank, empty
- CRT20N Cylinder Carrying Case
- GKNP kit

### GKNP20-T

- CRT20N Cylinder Carrying Case
- GKNP kit

### GKNP40-TC

- CY40-580 40 cu. Ft. Tank, empty
- CRT40N Cylinder Carrying Case
- GKNP kit

### GKNP40-T

- CRT40N Cylinder Carrying Case
- GKNP kit

GKNP40-TC Kit



## BLOW GUN ACCESSORIES

MODEL NUMBER	DESCRIPTION
<b>B306</b>	Blow Gun with Safety Tip, 1/4" F Inlet, 1/8" F Outlet
<b>B300</b>	Blow Gun without Safety Tip (BT6S)
<b>BT6S</b>	Standard Safety Tip (Used on B300)
<b>BT2</b>	Rubber Tip for flowing-out lines (Used on B300)
<b>BX6</b>	6" Extension Needle Tip (Used on B300)
<b>HBG-6</b>	6 ft. Blow Gun Hose
<b>CRT20N</b>	20 cu. Ft. Cylinder Carrying Case
<b>CRT40N</b>	40 cu. Ft. Cylinder Carrying Case

Refer to Regulator Section For Purging Regulator

